

Calibration

1. Open the Cricut Design Space App
2. Locate the profile in the top right corner, and select the drop-down menu
 1. Select "Settings"
3. When the Settings page pops up, select "Machines."
4. Find "Machine Calibration," then select the drop-down menu next to it and select "Maker 4."
5. Hit the "Start" button
6. Three options for calibration should pop up: "Rotary Blade, Knife Blade, and Print Then Cut."
 1. Selection for calibration depends on what it is you're trying to cut out. For stickers, do "Print Then Cut"; for vinyl, do "Knife Blade."
 1. Don't have the blade needed for "Rotary Blade," but if we did, it would be used for vinyl if you're making a fun shape using the rotary blade
7. Follow the directions given by the Cricut for calibration
8. Evaluate the cuts made from the calibration process. If it isn't right/accurate, do it again
 1. If it keeps getting worse, try restarting the Cricut (power off, unplug for 10-15 minutes, plug back in, and turn back on)

Revision #1

Created 2026-04-02 18:18:26 UTC by Febronia Farowez

Updated 2026-04-02 18:18:46 UTC by Febronia Farowez