


Push Buttons

Push Buttons

PCB-mount push buttons



Panel-mount push buttons





There are four ways (actually two because of symmetry) to connect to buttons. You can only use two at a time:



- ◆ **GND:** Connect this pin to ground.
- ◆ **VCC:** Connect this pin to a 5V or 3.3V power supply.
- ◆ **OUT:** Connect this pin to a digital input on your Arduino.

How It Works

- ◆ When the button is NOT pressed, pin A is NOT connected to pin B
- ◆ When the button is pressed, pin A is connected to pin B



Revision #1

Created 2026-06-12 18:08:37 UTC by Mariah

Updated 2026-06-12 18:08:54 UTC by Mariah