

# Setting up Quest Link

## Connecting the Quest 3 to workstation computers

1. Plug the headset into the white cable that's connected to the computer
2. Log in to the workstation computer
3. Open the Meta Quest application. If it's your first time using the computer, select "Log In."
4. A pop-up browser will pop up asking how you'd like to log in, select to use email, and type in the email (scil@su.edu). Then, when it asks for a code, select "use password instead" (scil1234) and select to "skip" when it asks you to update the password
5. Select "confirm" when it wants to be sure it's you, and then "Open in Meta Quest" and "open" again when the rectangle asking if you want to open the app outside of the browser at the top pops up

If you receive an Error

1. Open the SCiL Wiki and search "Error Login," "Rift Error," or any other similar keywords and select the first link
2. Copy the code at the bottom of the page, open the command prompt, insert the code there, and hit the "Enter" key on your keyboard. You'll know the action is completed when it says "task completed successfully."
3. Close the Meta Quest application, then open it again. It should allow you to select "continue."

6. The Meta Quest application will then have the Quest 3 pop up, and ask if this is your device. If it does, click yes. If it doesn't, put on the Quest 3, go to quick settings, and select the "questlink" option.
  1. It may also ask you to select what headset you're using, in which case you should select "Quest 3."
7. The Meta Quest application will then show if the cable link has been made. Hit continue twice
8. It will then tell you that the application is ready, at which point you can click "continue" again and put on the headset to use Meta Quest

---

Revision #1

Created 2026-02-02 19:13:40 UTC by Mariah

Updated 2026-02-02 19:13:58 UTC by Mariah